

Sustain Pedal






OWNER'S MANUAL — Please read before using this equipment.

Your RadioShack Sustain Pedal lets you easily add sustain effects to the sound of your keyboard. It is compatible with all RadioShack and Optimus keyboards with a sustain pedal input jack. It also fits many other keyboards.

Connect the sustain pedal's 1/4 inch (6.35mm) plug to your electronic keyboard's SUSTAIN jack.



Note: Some keyboards may require additional programming to assign the jack for sustain pedal use. Refer to the keyboard owner's manual for programming instructions.

To sustain notes or chords when playing the keyboard, depress the pedal.

To return to normal sound, release the pedal.

SPECIFICATIONS

Dimensions
(HWD) $1^{7}/16 \times 3^{1}/8 \times 3^{15}/16$ Inches
$(36 \times 80 \times 100 \text{ mm})$
Mono Plug Diameter ¹ /4 Inch (6.35 mm)
Cord Length 6 feet (1.83 m)
Weight 5.2 oz (150 g)

Limited Ninety-Day Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FIT-NESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PER-SON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RAdioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the

above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and la-bor; (b) replace the product with one of the same or similar design; or (c) re-fund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack, New or reconwhich a feature single-geometric tree property of Nadioclass. New or leading and dittioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other

rights which vary from state to state

RadioShack Customer Relations, 200 Taylor Street, 6th Floor, Fort Worth, TX 76102

We Service What We Sell

RadioShack Corporation Fort Worth, Texas 76102

42-4053 06A00 Printed in China



© 2000 RadioShack Corporation. All Rights Reserved. RadioShack and RadioShack.com are trademarks used by RadioShack Corporation.











